Ocala International Airport Non-Movement Area Training



> General Guidelines

- ALWAYS yield to aircraft and Emergency Vehicles!
- Maintain Situational Awareness at all times
- Follow Speed Limits

Movement Areas

- You are <u>NOT</u> authorized to enter the movement area unless escorted
- Do <u>NOT</u> cross movement area boundary markings

The Movement Area / Non Movement Area is the division of the airport areas controlled by the ATCT and areas that are uncontrolled. CONTROLLED UNCONTROLLED UNCONTROLLED

> Runways

- The markings and signs below identify the runways
- NEVER approach or cross the below markings or signs!



(Runway Hold Sign & Markings)



(Surface Painted Runway Hold Sign & Marking)

 If you are lost or require assistance, immediately contact Airport Operations at (352) 857-6505

(Continued on Reverse)

Airport Gate Access

- Do not allow others to use your badge
- Keep badge secure
- Report lost or stolen badges immediately
- Wait until the gate closes before you leave the area
- Do not allow others to "piggyback" or follow you through



> Airport Speed Limits

- 15 MPH on Aprons & Taxi-lanes
- 5 MPH within 50 feet of Aircraft
- Airport Operations & Emergency Vehicles (speed reasonable & prudent for conditions)

> Airport Security

- It is the responsibility of each airport user to assist with security and safety on the airport
- If you see suspicious activity, call 911 or Airport Operations at (352) 857-6505

Wildlife on the Airport

 If you see wildlife or large concentrations of birds on the airport, please notify Airport Operations at (352) 857-6505

**Your signature below acknowledges that you have received the required non-movement area training and will abide by the Airport's rules and regulations.

Printed Name:_	Date Trained:	
Signature:		

Current As Of: 02/23/21